

InBin-N... Fan belt monitoring via speed control switch up to 10.000 min⁻¹

InBin - N

InBin - N - 2

Subject to change!

Electrical fan belt switch for safe area (industrial applications).
24 VAC/DC supply voltage, output potential free switching contact.

Compact. Easy installation. Universal. Cost effective. Safe.

Type	Sensor	Supply	Range	Min. setting	Output switch	Max. ratings	Wiring
InBin - N	Namur DIN19234	24 VAC/DC	0..10,000 min ⁻¹	50 min ⁻¹	pot. free contact	250 VAC, 0.1A / 30 V, 0.5 A	SB 1.0 / SB 2.0
InBin - N - 2	as above, but with second switching output				2 pot. free contacts	250 VAC, 0.1A / 30 V, 0.5 A	SB 1.0 / SB 2.0

Application


Fan belt switch




Transducer with namur sensor



Installation kit 3



Installation kit 4



Description

The InBin-N speed control switch generation up to 10,000 min⁻¹ is a revolution for fan belt monitor transducers in HVAC systems, in chemical, pharmaceutical, industrial and Offshore-/Onshore plant). IP 66 protection, small dimension, universal functions and technical data guarantee safe operation even under difficult environmental conditions. The switching points are scalable within the maximum ranges. The integrated display is for actual value indication which can be switched off. All sensors are programmable on site without any additional tools. InBin-N-2 sensors are additionally equipped with a secondary switching output, which can be parameterized independently.

Highlights

- Industrial sensor
- Integrated junction box
- Power supply 24 VAC/DC
- Output potential free switching contact
- Display with backlight, can be switched off
- Scalable switching characteristics
- Scalable starting bypass time
- Compact design and small dimension (L × B × H = 180 × 107 × 66 mm)
- Robust aluminium housing in protection class IP 66
- Down to -20°C ambient temperature applicable
- Password locking
- Optional second switching output

Technical data	InBin - N...
Power supply	24 VAC/DC \pm 20% (19,2...28,8 VAC/DC) 50...60 Hz
Current, power consumption	150 mA, ~ 4 W, internal fuse 500 mA, without bracket, not removable
Galvanic isolation	supply – output 1,5 kV
Electrical connection	terminals 0,14...2,5 mm ² at integrated junction box
Cable entry	2 \times M16 \times 1,5 mm, cable diameter ~ \varnothing 5...10 mm
Display	LCD with backlight, display for configuration, user guidance, parameter and actual value indication via LEDs
Control elements	3 buttons for configuration
Housing protection	IP66 in acc. to IEC 60529
Housing material	aluminium casting, coated
Dimension / weight	L \times W \times H = 180 \times 107 \times 66 mm / ~ 950 g
Ambient temperature/-humidity	- 20...+ 50 °C / 0...95 % rH, non condensed
Storage temperature	- 20...+ 70 °C
Measuring range	0...10.000 min ⁻¹
Range scalable on site	50 min ⁻¹ ...10.000 min ⁻¹
Maintenance	maintenance free, nevertheless maintenance must be complied with regional standards, rules and regulations
Sensor circuit	internal circuit
Sensor	Namur, DIN 19234
Response time of sensor	T90 / 16 Sec.
Accuracy of rotary speed	\pm 0,5 % of end value
Setting range hysteresis	25 min ⁻¹ ...1000 min ⁻¹ (factory setting 50 min ⁻¹)
Start delay	5 sec.
Starting bypass time	3...240 sec. (via menu adjustable; preset 120 sec.)
Output switch	potentail free switching contact
	Ratings load max. 0,5 A @ 30 VAC/DC / 0,1 A @ 250 VAC / 0,1 A @ 220 VDC
	Ratings load min. 10 mW / 0,1 V / 1 mA
Mechanical life	10 \times 10 ⁶
Electrical life (rated load)	100 \times 10 ³
Wiring diagram (SB)	SB 1.0 / SB 2.0
Installation sensor / tubing	safe area


Approvals

CE-Mark	CE
EMC directive	RL 89/336/EC
Low voltage directive	RL 73/23/EC
Protection type	IP 66 in acc. to EN 60529
Elect. safety	Protection class I (grounded), Over voltage category II acc. to. EN 61010-1

Accessories

Installation kit 3	Mounting set for Namur sensor onto ventilators up to 20.000 m ³ /h
Installation kit 4	Mounting set for Namur sensor onto ventilators over 20.000 m ³ /h
MKR	Mounting bracket for round ducts up to \varnothing 600 mm

Dimensions / Drillings




Electrical connection

InBin-N... switches are equipped with a 24 VAC/DC power supply. The supply has to be connected at terminal 1 (-/~) and 2 (+/~). The electrical wiring must be realized via integrated junction box.

If supply voltage 24 VAC/DC different from the relay voltage must be used different or double isolated cables. The starting bypass delay can be activated by a short circuit of terminal 2 and terminal 3 (AUB). An active bypass delay is indicated with green blinking LEDs.


Attention: Do not open covers when circuits alive!

Wiring Diagram InBin-N / InBin-N-S2




Namur sensor connector

SB 2.0



Display and Buttons



Change operation-/parametrisation mode

To change from operation to parametrisation mode push the enter button for minimum 3 seconds. Back over the menu save.

Indication of data logging

The blinking unit in the display shows that data is received and the device is working.


Password input

The default / delivery setup is **0000**. In this configuration the password input is not activated. To activate a password change the 4 digits into your chosen numbers (e.g. 1234) and press Enter.

Please keep your password in mind for next parameter change!

Due to a new parameter setup the password is requested.

Installation



- Do not open covers when circuits alive
- The cable must be installed in a fixed position and protected against mechanical and thermal damage.
- Connect protection earth
- Avoid thermal transfer from sensor to transducer (ensure max ambient temperature !)
- Ambient temperature -20...+50 °C @ T6
- Close all covers, entries with min IP66
- All transducers are maintenance free.
- Nevertheless maintenance must comply with regional standards, rules and regulations.
- Close after settings all covers and cable entries tight min. IP66.
- For outdoor installation a protective housing against rain, snow and sun should be applied
- For electrical connection use the integrated junction box.

Important information for installation and operation

Installation, Commissioning, Maintenance

The cable has to be drawn through the cable gland. After electrical connection the cable gland must be fixed tight. IP66 must be fulfilled.

In acc. with operation InBin switches are maintenance free. Nevertheless maintenance must comply with regional standards, rules and regulations.

The sensors must not be opened by the customer. For outdoor installation a protective housing against rain, snow and sun should be applied. For electrical connection use the internal junction box.

Attention: Note the national rules before opening the internal junction box. Cut off the power supply.

A. Supply and Contact

Wires from safety extra low voltage must be separated from others. Only at 24 VAC/DC is supply and signal wires in one cable permitted. All others use separate or double isolated cables. Install overload protection fuse < 10 A.

B. Long cabling


For using long signal wires, shielded cables are recommended. The shield must be connected to the InBin-P switch inside the terminal box.

C. Separate ground wires


Use for supply and signal wires a separate ground.












































Parametrisation and commissioning of InBin-N transducers
Preparation of parametrisation/operation

 Operation ↔ Parametrisation, push  for 3 sec.

 If password (PW) protection is active: put PW in, push 

Change operation- / parametrisation mode

 To change from operation to parametrisation mode push „enter button“  for minimum 3 seconds. Back over the menu save.


Menu	Function	Enter	Indication	Select	Enter	Next indication	Next selsction	Enter	Next menu
Menu 1	no function - menu skip								
Menu 2	no function - menu skip								
Menu 3	set 1 select switching point 1	←Menu 3→ SEt 1		Menu 3 700 min ⁻¹	  	adjust set 1			
Menu 4	set 2* select switching point 2	←Menu 4→ SEt 2		Menu 4 1500 min ⁻¹	  	adjust set 2			
Menu 5	hysteresis** select hysteresis	←Menu 5→ HYSt		Menu 5 100 min ⁻¹	  	adjust hysteresis			
Menu 6	mode** select switching characteristic	←Menu 6→ ModE		Menu 6 UP	  	norm. open (no), norm. closed (nc)	Menu 6 nc	  	
Menu 7	no function - menu skip								
Menu 8	no function - menu skip								
Menu 9	no function - menu skip								
Menu 10	no function - menu skip								
Menu 11	no function - menu skip								
Menu 12	time select time for starting bypass (AUB)	←Menu 12→ E IME		Menu 12 100 s	  	adjust bypass time in sec.			
Menu 13	lamp select backlight	←Menu 13→ LAMP		Menu 13 ON	  	on, off			
Menu 14	no function - menu skip								
Menu 15	security select password	←Menu 15→ SECU		Menu 15 0000	  	enter password			
Menu 16	save select save data	←Menu 16→ SAVE		Menu 16 YES	  	no, yes, return, default setting			

* available for 2-stage version only (InBin-N-2)

** useable in professional mode only (see following section)

Using the menu

To beware complexity during the parametrisation process, the InBin-N has a predefined setup for the hysteresis (menu 5) and the operation mode (menu 6). This default setting is designed for fan speed monitoring applications. The switching characteristic for that operationmode works as defined in the illustration below:



Menu 5 and Menu 6 will normally skipped during the parametrisation process.

Professional mode

If the user wants to change the factory setting for hysteresis and the operation mode, press the „right“-button for more than 3 seconds. (Make sure that the main-menu is selected - the arrows next to the „MENU“-icon must be visible) Now „Professional“-mode will be active and two further menus were added: menu 5 „hysteresis“ and menu 6 „mode“.

Using the menu 6 „mode“

First of all the user has to define the device normal range. For example:

- The device should indicate (green LED) if the fan speed is under the setpoints, mode „down-range“ has to be selected. With other words: the measure value is normally under the setpoints.
 - The device should indicate (green LED) if the fan speed is over the setpoints, mode „up-range“ has to be selected. (The measure value is normally over the setpoints.)
 - The device should indicate (green LED) if the fan speed is between the setpoints, mode „mid-range“ has to be selected. (The measure value is normally between the setpoints.)
- This mode is only for 2-stage devices available (InBin-N-2).


In the second step the switching characteristic of the output relay has to be selected:

- „normally closed“ (nc): if the measure value is in the normal range (see above), the corresponding relays were closed.
- „normally open“ (no): if the measure value is in the normal range (see above), the corresponding relays were open.

You'll find a detailed description of all possible settings in the following section.


Switching characteristic „up-range“ – „normally closed“

„Up-range“: the normal range is above setpoint 1 and setpoint 2




Switching characteristic „up-range“ – „normally open“

„Up-range“: the normal range is above setpoint 1 and setpoint 2




Switching characteristic „mid-range“ – „normally closed“

„Mid-range“: the normal range is between setpoint 1 and setpoint 2 (for 2-stage devices only)




Switching characteristic „mid-range“ – „normally open“

„Mid-range“: the normal range is between setpoint 1 and setpoint 2 (for 2-stage devices only)



Switching characteristic „down-range“ – „normally closed“

„Mid-range“: the normal range is under setpoint 1 and setpoint 2



Switching characteristic „down-range“ – „normally closed“

„Mid-range“: the normal range is under setpoint 1 and setpoint 2

