


CP RANGE

COMPACT PNEUMATIC ACTUATORS

**INSTALLATION
AND
MAINTENANCE
MANUAL**



SECTION	CONTENT	PAGE
1	Introduction	3
2	Installation	3
3	Maintenance	5
4	Grease Specification	6
5	Cylinder Seal Replacement	7
6	Fault Detection	8
7	Drawing / Parts List	9

1.0 Introduction

This manual is produced to enable a competent user to install, operate, adjust, inspect, and maintain Rotork Fluid Systems CP range actuators. Users are responsible to follow the instructions in this manual as well as any additional documentation that has been supplied regarding the actuator or accessories supplied by Rotork Fluid Systems. Should further information or guidance relating to the safe use of CP Range actuators be required, it will be provided on request. Users are also responsible to be familiar with and follow any relevant legislation or statutory provisions regarding health and safety.

It is the users responsibility to ensure that the equipment is operated in a safe manner and that any personnel working with or on the equipment are properly trained for the work they are performing and are also aware of their responsibilities relating to health and safety in the workplace. It is extremely important that precautions are taken to avoid spark or static discharge in any areas of potentially explosive atmosphere.

All Rotork Fluid Systems actuators are tested prior to despatch. Job specific documentation is shipped with the actuator. Test certificates and replacement documentation are available upon request. The latest general information regarding any Rotork product is available on our website www.rotork.com.

INSTALLATION

2.0 Installation

2.1 Electrical Considerations

- 2.1.1 Any electrical connections required are the responsibility of the user. Connection documentation is supplied with the actuator. Refer to the applicable wiring diagram to identify functions of terminals. Verify that the electrical supply characteristics are compatible with the supplied actuator control components.
- 2.1.2 Only appropriate certified explosion-proof entry reducers, glands or conduit may be used if the unit is installed in a hazardous area. Remove any plastic transit plugs. Make cable entries appropriate to the cable type and size. Ensure that threaded adaptors, cable glands or conduit are tight and fully waterproof. Seal unused cable entries with a steel or brass plug. In hazardous areas an appropriately certified threaded blanking plug must be used.
- 2.1.3 Access to live electrical conductors is forbidden in hazardous areas unless done under a special permit to work. Otherwise, all power should be isolated and the unit moved to a non-hazardous area for repair or attention.
- 2.1.4 The actuator and control components must be protected from electrical spikes, surges, and lightning strikes as well as magnetic or electro-magnetic fields. This is the responsibility of the user.

2.2 Motive Power Supply (pneumatic, hydraulic)

- 2.2.1 Ensure that the actuator will not be exposed to pressure in excess to the maximum rating as indicated on the nameplate.
- 2.2.2 Verify that medium composition (e.g., filtration, hydration) correspond to that for with the actuator was manufactured. Rotork Fluid Systems must be contacted to verify compatibility of any proposed changes to supply medium.
- 2.2.3 Ensure that throughout the installation that there are no leaks of a potentially explosive supply medium (e.g., natural gas).

Note: Depending upon control circuit design, pneumatically powered actuators may exhaust the power supply gas to atmosphere in the course of normal operation. This may present an unacceptable hazard in some applications. Consult Rotork Fluid Systems if in doubt as to the suitability of the equipment supplied for your application.

2.3 Maximum Allowable Temperature

- 2.3.1 The maximum temperature allowable for standard build actuators is 100°C (212°F). Other maximum temperature build options are available. It is the responsibility of the user to ensure that the maximum allowable temperature as indicated on the nameplate is not exceeded and also, in the case of sites where a potentially explosive atmosphere may exist, that the surface temperature of the actuator does not exceed the ignition point of the potentially explosive atmosphere.
- 2.3.2 Be aware that the temperature of the contents of the valve/pipeline as well as that of the power supply gas will affect actuator temperature. A build up of dust or dirt on the actuator can inhibit cooling and contribute to increased surface temperatures. The user should plan and provide for a periodic cleaning/maintenance program that will maintain the installation environment per the guidelines set forth in EN 1127-1 par 6.4.2.

2.4 Operating Environment

- 2.4.1 The user must ensure that the operating environment and any materials surrounding the unit cannot lead to a reduction in the safe use of, or the protection afforded by the actuator. Where appropriate, the user must ensure the actuator is suitably protected against its operating environment including, but not limited to, lightning strikes, vibration sources and vehicular movement.
- 2.4.2 If the unit has a nameplate indicating that it is suitable for installation in potentially explosive atmosphere (hazardous area), it must not be installed in a hazardous area that is not compatible with the gas groups and temperature class defined on the nameplate.

2.5 Mechanical Considerations

- 2.5.1 It is recommended that before lifting an actuator onto a valve, great care is taken to ascertain the position of the valve and orientate the actuator accordingly.
- 2.5.2 Rotork actuators can be mounted on valves in almost any desired position. It is usual however to align the centerline of the cylinder to the centerline of the associated pipe work.
- Note: Certain accessory and control components e.g., filter drains, hydraulic reservoirs; require proper orientation with respect to gravity to function properly. Contact Rotork Fluid Systems if in doubt.*
- 2.5.3 Ensure all fasteners are adequately tighten to avoid loosening during the course of operation, taking into account vibration induced by the dynamics of the pipeline.
- 2.5.4 All tubing used to provide pneumatic/hydraulic power to the actuator must be free from contaminants and debris. Ensure tubing runs are adequately fastened and supported to minimise repetitive stress induced by any vibration induced by the dynamics of the pipeline.
- 2.5.5 When the actuator has been bolted to the flange or adapter, the position of the stop bolts should be checked to ensure full opening and closing of the valve. If these end of travel positions are not correct, the stop bolts may be adjusted by first loosening the fixing nut and then screwing the bolts in or out until desired end position is obtained. Stroke the yoke away from the stop bolt when adjusting, then return it to check position. When the correct positioning is obtained, re-tighten the fixing nut.
- 2.5.6 Certain valves incorporate their own stops. In these cases it is recommended that the actuator stop bolt positions coincide with the valve stop positions.
- 2.5.7 Ensure there are no leaks from any pneumatic or hydraulic connections. Tighten as required.
- 2.5.8 Once in position, the actuator should operate the valve with a smooth continuous action. If uneven operation occurs, the pneumatic/hydraulic power supply should be checked for correct pressure and volume flow. Flow may be restricted by undersize pipe or fittings. These could throttle the flow thus reducing the pressure and volume at the actuator and causing intermittent motion. Further fault detection procedures are outlined in Section 6.

3.0 Maintenance

- 3.1 Rotork actuators are designed to work for long periods of time in the most severe conditions. However, a preventative approach to maintenance helps prevent costly down time and can actually reduce the cost of ownership. Rotork can provide an actuator maintenance contract tailored to meet each customer's individual requirements.
- 3.2 Any personnel working with or on the equipment must be properly trained for the work they are performing and be aware of their responsibilities relating to health and safety in the workplace.
- 3.3 No inspection or repair should be undertaken unless it conforms to any applicable hazardous area certification requirements. Under no circumstances should any modification or alteration be carried out on the unit as this could invalidate the certification.
- 3.4 Before performing maintenance, the actuator should be isolated from remote control signals and the pneumatic/hydraulic power supply. The system should be then be relieved of any internal pressure prior to disassembly.
- 3.5 Improper operation, adjustment or maintenance of the actuator and controls may, depending on the application, release potentially explosive gas and or dangerous liquids.
- 3.6 After maintenance has been performed and re-assembly completed, follow the inspection guidelines as outlined section 3.6.
- 3.7 Periodic Inspection
 - 3.7.1 Ensure that the actuator correctly operates the valve within the required cycle time. The actuator should be cycled several times with all the existing controls e.g., remote control, local control and manual override; particularly if the actuator is not frequently operated.
 - 3.6.2 Verify that the power gas supply pressure value is within the required range.
 - 3.7.3 Visually inspect external components of the actuator for physical damage.
 - 3.7.4 Check pneumatic/hydraulic connections for leakage. Tighten pipe fittings as required.
 - 3.7.5 Remove dust and dirt build-up from all actuator surfaces. They can inhibit cooling thus raising the temperature of the actuator above the maximum allowable limit.
 - 3.7.6 Inspect actuator paint work for damaged to ensure continued corrosion protection. Touch-up as required to applicable paint specification.

4.0 Grease and Hydraulic Oil Specifications

4.1 Grease Specification

Manufacturer:	Mobil
Trade name:	Mobiltemp 78
Colour:	Gray/black
Soap type:	Inorganic
Oil type:	Mineral
Consistency (NLGI GRADE)-ASTM D217:	1
Worked penetration at 25°C-ASTM D217:	295/325 dmm
Dropping point - ASTM D2265	260°C
Viscosity of base oil at 40°C-ASTM D445:	485 cSt
Viscosity of base oil at 100°C-ASTM D445:	32 cSt

Note: This is the standard grease specification for Rotork Fluid Systems actuators. If an alternative was specified and/or supplied, it is noted in job specific documentation, which is available upon request.

4.2 Hydraulic Oil Specification

Manufacturer:	Mobil
Trade name:	DTE 11
Viscosity at 40°C:	16.5 cSt
Viscosity at 100°C:	4.2 cSt
Viscosity index ASTM:	168
ISO Grade:	16
Pour point:	-42°C
Specific weight at 15°C:	0.85 kg/dm ³
Equivalent to:	Statoil - Hydraway HVX-A15

Note: This is the standard hydraulic oil specification for Rotork Fluid Systems actuators. If an alternative was specified and/or supplied, it is noted in job specific documentation, which is available upon request.

5.0 Cylinder Seal Replacement

When the cylinder seals must be replaced, either due to a leak or as part of a preventative maintenance programme, follow the procedure outlined below (reference drawing on page 9).

5.1 Disassembly

5.1.1 Ensure that the power gas supply to the actuator is shut off. For spring-return actuators, the actuator must be positioned so that the spring is fully extended.

5.1.2 Disconnect power gas supply line from the end flange (item 4).

5.1.3 Unscrew the tie rods (item 24).

5.1.4 Remove the end flange (item 4) and the o-ring (item 14*) from the end flange.

5.1.5 Remove the cylinder tube (item 7) and o-ring (item 14*) that is between the cylinder tube and spring container (item 30) on spring-return actuators or, on double-acting actuators is between the cylinder tube and housing (item 21).

5.1.6 For spring-return actuators, verify that the actuator is positioned so that the spring is fully extended as instructed in step 5.1.1.

Note: When the spring is fully extended some spring force remains against the piston.

5.1.7A Double-acting actuators only: Unscrew the piston fixing bolt (item 10) and remove it and washer (item 8).

5.1.7B Spring-return actuators only: Begin to unscrew the piston fixing bolt (item 10). Ensure that the piston is free and sliding on the shaft as the fixing bolt is unscrewed so that all spring force is released before the fixing bolt is disengaged. Also ensure that threaded bushing (item 18C) remains fixed inside the axial bar (item 18B). Remove piston fixing bolt (item 10) and washer (item 8).

5.1.8 Remove the piston (item 5).

5.1.9 Remove the o-rings outside (item 6) and inside (item 9) the piston.

5.2 Reassembly

5.2.1 Carefully clean the o-ring grooves and all sealing surfaces.

5.2.2 Lubricate all the new o-rings with clean grease and place them in the proper locations.

5.2.3 The assembly procedure is the direct reverse of the disassembly procedure.

5.2.4 Reconnect power gas supply lines to the actuator.

5.2.5 Cycle the actuator several times. It's movement should be smooth and continuous. If not, refer to Section 6, Fault Detection.


* On double-acting actuators item 14 is used in two locations: on both end of the cylinder tube sealing against the end flange and the housing. On spring-return actuators item 14 is used in three locations: between the end flange and cylinder tube, between the cylinder tube and spring can, and between the spring can and the housing.

RECOMMENDED TIGHTENING TORQUE		
BOLT SIZE	NM	FT. LBS
M8	20	15
M10	40	30
M12	55	40
M14	110	81
M16	220	162
M20	430	317
RECOMMENDED TIGHTENING TORQUE EXCEPTIONS		
ACTUATOR TIE RODS (AND CYL FLG TO HOUSING CP065 ONLY)		
M16 (CP055)	130	96
M16 (CP065)	180	133
ACTUATOR HOUSING TO VALVE OR ADAPTER FLANGE		
M10 (CP045)	45	33
M12 (CP055)	85	63
M20 (CP065)	300	221

6.0 Fault Detection

In the unlikely event of a fault developing, the following Fault Location Table is provided to assist the maintenance technician. This table is designed to cover as wide a range of Rotork Fluid Systems actuators as possible. Reference to equipment not supplied should be ignored.

SYMPTOM	CAUSE	REMEDY
6.1 Erratic movement	6.1.1 Irregular supply of operating medium.	6.1.1.1 Check operating medium for consistent supply pressure and correct as necessary.
	6.1.2 Inadequate lubrication.	6.1.2.1 Dismantle, re-lubricate and reassemble.
	6.1.3 Worn parts.	6.1.3.1 Dismantle. Visually inspect for significant wear. Actuator replacement may be required.
	6.1.4 Defective valve.	6.1.4.1 Consult the valve manufacturer's documentation.
6.2 Short stroke	6.2.1 Incorrectly set stops (valve and /or actuator).	6.2.1.1 Check the position of the travel stops and readjust as necessary.
	6.2.2 Hardened grease.	6.2.2.1 Dismantle, remove any hard grease, re-lubricate and reassemble.
	6.2.3 Debris left in the cylinder or housing during maintenance.	6.2.3.1 Disassemble cylinder assembly to remove debris. Reassemble cylinder assembly as necessary.
	6.2.4 Defective valve.	6.2.4.1 Consult the valve manufacturer's documentation.
6.3 Apparent lack of power	6.3.1 Inadequate supply pressure.	6.3.1.1 Ensure supply pressure is above the minimum operating pressure of the actuator and that output torque produced at supply pressure exceeds valve torque demand.
	6.3.2 Incorrect speed control settings.	6.3.2.1 Adjust speed controls to increase flow.
	6.3.3 Exhaust port blocked.	6.3.3.1 Remove and clean the exhaust port silencers and replace.
	6.3.4 Pipe work blocked, crushed or leaking.	6.3.4.1 Examine the pipe work for blockages, crushed pipe or leakage. Clear or replace as necessary.
	6.3.5 Defective controls.	6.3.5.1 Examine the controls, refurbish or renew as necessary. Refer to component manufacturer's documentation.
	6.3.6 Defective piston seal.	6.3.6.1 Dismantle the cylinder assembly, remove the defective piston seal. Fit new seal and reassemble.
	6.3.7 Defective rod seal.	6.3.7.1 Dismantle the cylinder assembly, remove the defective rod seal. Fit new seal and reassemble.
	6.3.8 High valve torque or valve seized.	6.3.8.1 Consult the valve manufacturers documentation.



ITEM	DESCRIPTION	MATERIAL	QTY
1	Stop Screw – Housing	Carbon Steel	1
2	Stop Nut	Carbon Steel	2
3	O-ring	Buna-N	2
4	End Flange	Ductile Iron	1
5	Piston	Carbon Steel	1
6	O-ring	Buna-N	1
7	Cylinder Tube	Carbon Steel (Nit-ox® treated)	1
8	Washer	Carbon Steel	1
9	O-ring	Buna-N	1
10	Piston Retaining Bolt	Alloy Steel	1
11	Retaining Ring	Spring Steel	1
12	Key	Carbon Steel	1
13	Spring	Spring Steel	1
14	O-Ring	Buna-N	*
15	O-ring	Buna-N	4
16	Bushing	Steel/Bronze/Teflon	1

ITEM	DESCRIPTION	MATERIAL	QTY
17	Spring Pin	Spring Steel	1
18A	Axial Bar – Double-Acting	Alloy Steel (Nit-ox® treated)	1
18B **	Axial Bar – Spring-Return	Alloy Steel (Nit-ox® treated)	1
18C **	Bushing – threaded	Alloy Steel	1
19	Bushing	Steel/Bronze/Teflon	1
20	Housing Plug (not shown)	Carbon Steel	1
21	Housing	Carbon Steel	1
22	Stop Screw – End Flange	Carbon Steel	1
23	Yoke	Ductile Iron	1
24	Tie Rod	Alloy Steel	4
25	Adapter Plate	Ductile Iron	1
26	Washer	Carbon Steel	2
27	Bushing	Steel/Bronze/Teflon	2
28	Yoke Pin	Alloy Steel (Nit-ox® treated)	1
29	Output Shaft	Alloy Steel (Nit-ox® treated)	1
30 **	Spring Container	Carbon Steel	1
31 **	Spring	Spring Steel	1

* Quantity (2) for double-acting, (3) for spring-return.

** Spring-return actuators only.

A full listing of our worldwide sales and service network is available on our website.

Corporate Headquarters
Rotork plc
tel +44 (0) 1225 733200
fax +44 (0) 1225 333467
email mail@rotork.com

Controls
Fluid Systems
Gears
Instruments
Site Services

www.rotork.com