


rotork®

Keeping the World Flowing
for Future Generations

CKQ Range

Safe Use and Installation Manual



Modular Design Electric Valve Actuators

CK range



Table of Contents

1. Introduction	4	9. Commissioning	15
2. Safety	5	9.1 Atronik Interface	15
2.1 Standards and Directives	5	9.2 Centronik Interface	16
2.2 Competency	5	9.3 Centronik Navigation	17
2.3 Commissioning	5	9.3.1 Local Selector input	17
2.4 Warnings	5	9.3.2 Setting Tool Input	17
3. Transport and Storage	6	9.4 Centronik Feedback	18
4. Actuator Identification	7	9.4.1 Arrow Identification	18
4.1 CKQ Standard	7	9.4.2 Confirmation Feedback	18
4.2 CKQA Atronik	8	9.5 Basic Mechanical Switch Mechanism Setting	19
4.3 CKQc Centronik	9	9.5.1 Instructions	19
5. Preparing the Drive Bush	10	9.5.2 Set Position Limits	20
5.1 Drive Bush	10	9.6 End of Travel Action	21
5.1.1 Disassembly	10	9.6.1 Atronik	21
5.1.2 Reassembly	10	9.6.2 DIP switch functions	21
6. Mounting the Actuator	11	9.6.3 Centronik	22
6.1 Weights and Measures	11	9.7 Centronik Setting Adjustment	23
6.2 Mounting the Actuator	12	9.7.1 Entering Configuration mode	23
7. Cable Connections	13	9.7.2 Entering the User Password	23
7.1 Terminal block layout	13	9.8 Secondary Function Setting	24
7.2 Earth/Ground Connections	14	10. Maintenance, Monitoring and Troubleshooting	24
7.3 Removing the plug and socket	14	11. Disposal / Recycling	25
7.4 Cable entry	14	12. Environmental	25
8. Operating Your Actuator	14	13. Components of The Modular CKQ Actuator Design	26
8.1 Operating by Hand	14		
8.2 Operating Electrically	14		

1. Introduction

⚠ This manual contains important information to prevent damage in their handling, setting and use. It is essential to follow and observe all the points. Please observe all National Legislation for health and safety regulations, standards and directives applicable.

This works and the information it contains are the property of Rotork. The information it contains shall not be reproduced or disclosed, in whole or in part without the prior written consent of Rotork.

Instructions included in this document are applicable for all variants of the CKQ Range - including but not limited to; CKQ Standard, CKQA and CKQc.

This manual is produced to enable a competent user to install, operate, adjust and inspect the CKQ Range of valve actuators.

These user instructions are provided subject to the following conditions and restrictions:

This document contains information of a proprietary nature belonging to Rotork. Such information is supplied solely for the purpose of assisting users of the CKQ Range of valve actuators in its installation and maintenance.

The text and the graphics included in this document are for the purpose of illustration and reference only. The specifications on which they are based are subject to change without notice.

Information in this document is subject to change without notice.

This manual provides instruction on:

- Manual and electrical operation
- Preparation and installation of the actuator onto the valve
- Basic commissioning
- Maintenance

Refer to Publication PUB111-133 for repair, overhaul and spare part instructions.

2. Safety

All users working with this product must be familiar with and observe the safety and warning instructions given in this manual. To avoid personal injury or property damage safety instructions and warning signs on the product must be observed.

Due consideration of additional hazards should be taken when using the product with other equipment. Further information and guidance relating to the safe use of the product is provided on request.

These instructions must be observed otherwise safe use and operation cannot be guaranteed.

2.1 Standards and Directives

Rotork products are designed and manufactured in compliance with internationally recognised standards and directives. EC Declaration of Conformity and Incorporation are available on request. It is the responsibility of the end user or contractor to ensure that the legal requirements, directives, guidelines, national regulations and recommendations applicable to the site of installation are met with respect to assembly, electrical connections and operation.

2.2 Competency


The user and those persons working on the equipment should be familiar with and observe their responsibilities under any statutory provisions relating to occupational health and safety regulations. Before working on this product users should have thoroughly read and understood these instructions.

Only persons competent by virtue of their training and experience should install, maintain and repair Rotork actuators.


2.3 Commissioning


It is important to check that all settings meet the requirements of the application before commissioning the product. Incorrect settings might cause damage to valves or other property. Rotork will not be held liable for any consequential damage.


2.4 Warnings


 **This information is needed to avoid a safety hazard, which might cause bodily injury**


 **This information is necessary to prevent damage to the product or other equipment**


 **WARNING: Motor Thermostat / Motor Temperature**
Under normal operation the surface temperature of the actuator's motor cover can exceed 60 °C above ambient. Failure to correctly connect the thermostat may lead to electrical hazards and invalidate the electrical safety case and any safety approvals. Surface temperatures of motor enclosures may reach temperatures which can cause discomfort or injury to personnel accidentally coming into contact with hot surfaces. Protection should be provided by the user to protect against accidental contact with hot surfaces. Failure to observe this precaution could result in bodily injury.

 **WARNING: Surface Temperature**
The installer/user must ensure that the actuator's surface temperature rating is not influenced by external heating/cooling effect (e.g. valve/pipeline process temperatures).

 **CAUTION: Enclosure Materials**
The CKQ Range of valve actuators are manufactured from aluminum alloy with stainless steel fasteners. The user must ensure that the operating environment and any materials surrounding the actuator cannot lead to a reduction in the safe use of, or the protection afforded by, the actuator. Where appropriate the user must ensure the actuator is suitably protected against its operating environment.

 **WARNING: Unexpected Start up**
Actuator may start and operate at any time when power is applied. This will be dependent on remote control signal status and actuator configuration.

 **WARNING: Unit Weight**
The actuator weight is shown on the nameplate. Care must be taken to transport, move or lift the actuator safely. Lifting information is available in section 6.

 **WARNING: Service Altitude**
The actuator installation altitude must be restricted to less than 2000 m as defined by IEC 61010-1 (Safety requirements for electrical equipment for measurement, control and laboratory use).

3. Transport and Storage

During transportation, care should be taken to ensure that your actuator is protected from impact. In the unfortunate event of your actuator receiving an impact, the actuator should be inspected by a Rotork trained technician.

If your actuator cannot be installed immediately, store it in a clean, dry ventilated location that is off the floor and protect it from dust and dirt.


CKQ Range valve actuators are supplied with temporary transit cable entry plugs. These are for short term use and if the unit is likely to be stored for a period of time, these must be replaced with metal or environmental proof plugs which have been sealed with PTFE tape.

If the actuator has to be installed but cannot be cabled, it is recommended that the transit cable entry plugs are replaced with metal or environmental proof plugs which are sealed with PTFE tape until you are ready to connect the incoming cables.

The CKQ plug and socket assembly will preserve internal electrical components perfectly if left undisturbed. Rotork cannot accept responsibility for deterioration caused on-site once the covers are removed. Every CKQ Range actuator is fully tested before leaving the factory to give years of trouble free operation, providing it is correctly commissioned, installed and sealed. Technical documentation that is supplied with each unit must be kept safe for future reference.


4. Actuator Identification

4.1 CKQ Standard



Electric Actuator Nameplate


The actuator name plate will enable you to identify your unit.
Example below:



Mark	Description
1	Facility Address
2	Actuator Model and Flange Size
3	Serial Number
4	Wiring Diagram Number
5	Power Supply
6	Enclosure Protection
7	Output Speed (Stroke Time)
8	Maximum Rated Torque
9	Lubricant
10	Operating Temperature Range
11	Maximum Unit Weight
12	Manufacturing Date (MM / YYYY)
13	Tag Information (if applicable)
14	Certification Marks


4. Actuator Identification

4.2 CKQA Atronik



Atronik Module Nameplate


The Atronik name plate will enable you to identify your unit.
Example below:



Mark	Description
1	Model
2	Serial Number
3	Power Supply
4	Customer Supply
5	Backup Supply
6	P max
7	Wiring Diagram
8	Internal Diagram
9	Temperature Range
10	Manufacturing Year
11	Serial No. Code Bar
12	QR Code
13	IP Degree
14	Address


4. Actuator Identification

4.3 CKQc Centronik



Centronik Module Nameplate

The Centronik name plate will enable you to identify your unit.
Example below:



Mark	Description
1	Model
2	Serial Number
3	Main Power Supply
4	Remote Control Supply
5	Internal Customer Supply
6	Backup Supply
7	Maximum Power Rating
8	Customer Wiring Diagram
9	Internal Unit Diagram
10	Temperature Range
11	Enclosure Rating
12	Manufacturing Date
13	Unit Barcode (Factory Use)
14	QR Code
15	Capacitor Value (1ph only)
16	Spare Line (Tag Information)

5. Preparing the Drive Bush

5.1 Drive Bush

⚠ NOT suitable for axial loads/forces.

⚠ Drive bush is non-thrust type B.


5.1.1 Disassembly

Turn the actuator onto its side.

Using a suitable tool, remove the captive bolt (1) while pulling the drive bush (2) out. The drive bush will detach from the centre column.

5.1.2 Reassembly

Refitting is the reverse of removal, ensuring that the drive bush is greased and the bolts are tightened to the correct torque. See Section 6.2 Table A.



6. Mounting the Actuator

⚠ CAUTION: Do not lift the actuator/valve combination via the actuator. Always lift the combination via the valve. Each lift must be assessed on an individual basis.

⚠ WARNING: Always ensure that the actuator weight is supported from the actuator body and not the Atronik or Centronik control module.

⚠ WARNING: Ensure the actuator is fully supported until full valve engagement is achieved and the actuator is secured onto the flange.

Ensure the valve is secure before fitting the actuator as the combination may become unstable.

If it is necessary to lift the actuator using mechanical equipment, certified slings should be used. Lifting and slinging should always be carried out by competent trained personnel.

The actuator base dimensions/couplings conform to ISO 5211 or MSS SP - 101.

Actuator to valve fixing must confirm to material specification ISO Class 12.9, yield strength 1,080 N/mm².

6.1 Weights and Measures

Weight - kg (lbs)

Frame Size	Gross
135	22.5 (49.6)
400/610	30.5 (67.2)
1000	36.5 (80.5)

Note: Weight stated are the maximum possible within that model range.

Oil Capacity

Frame Size	Litres	Pt-US
135	0.25	0.53
400/610	0.85	1.80
1000	1.20	2.54



CKQ Standard actuator being lifted in a sling.



CKQ Atronik actuator being lifted in a sling.



CKQ Centronik actuator being lifted in a sling.

6. Mounting the Actuator

6.2 Mounting the Actuator

Ensuring that the drive bush fits the input shaft/key and has adequate axial engagement then fit into the actuator as described in Section 5.1.

Engage HAND, offer up the actuator to the valve, turning the handwheel to align the drive bush. Tighten the mounting bolts to the required torque - Table A.

Table A: Required Torque

Metric		Torque	
Flange	Fixing	Nm	lbf.ft
F05	M6	5.4	4.0
F07	M8	26.1	19.3
F10	M10	51.6	38
F12	M12	42.9	31.6
F14	M16	219.8	162.1
F16	M20	198.2	146.2
Imperial		Torque	
Flange	Fixing	Nm	lbf.ft
FA05	1/4"	6.7	4.9
FA07	5/16"	24.3	17.9
FA10	3/8"	42.3	31.2
FA12	1/2"	50.8	37.4
FA14	5/8"	205.3	151.4
FA16	3/4"	170.8	126.0

7. Cable Connections

7.1 Terminal block layout


⚠ WARNING: Ensure all power supplies are isolated before removing any covers.

Do NOT run the actuator to limits with incorrect phase rotation.

Safety Instructions in Section 2 of this document must be observed and only persons competent by virtue of their training and experience should carry out electrical connection.

For unit specific wiring, please refer to the provided wiring diagram. These can also be downloaded from www.rotork.com

⚠ WARNING: For units including an internal heater. It is important to isolate the heater supply when heating is not required.



7. Cable Connections

7.1 Terminal block layout *contd.*

A switch or circuit breaker must be included in the wiring installation to the actuator. The switch or circuit breaker must meet the relevant requirements of IEC60947-1 and IEC60947-3 and be suitable for the application. The switch or circuit breaker must not disconnect the protective earth conductor. The switch or circuit breaker must be mounted as close to the actuator as possible and shall be marked to indicate that it is the disconnect device for that particular actuator.

⚠ WARNING: The actuator must be protected with overcurrent protection devices, see relevant Motor Performance data sheet.

⚠ CAUTION: Power supply cables must have sufficient mechanical protection properties to meet installation requirements and be screened to comply with EMC requirements of the installed actuator. Suitable methods include armoured and/or screened cables or cables contained within conduit.

IP68 sealing protection can only be achieved by ensuring that the correct cable glands are fitted and any remaining entries are correctly sealed up.

7.2 Earth/Ground Connections

⚠ WARNING: Risk of Electric Shock - Do not operate the actuator with the Protective Earth (PE) conductor disconnected

The actuator is supplied with two earthing points. A 6 mm diameter hole is tapped adjacent to the conduit entries on the main casting for attachment of an external protective earthing strap. An internal 6 mm earth connection is also provided however it must not be used alone as the protective earth connection.

7.3 Removing the plug and socket

Using a 5 mm Allen (Hex) key, loosen the four captive screws evenly and remove the cover. Do not attempt to lever off the cover as you may damage the o-ring seal.

7.4 Cable entry

The cable entries into the plug and socket are M20 x 1.5p, M25 x 1.5p and M32 x 1.5p. Remove the transit plugs and make cable entries appropriate to the cable type and size.

Ensure that threaded adaptors, cable glands or conduit are tight and fully waterproof. Seal unused cable entries with steel or brass threaded plugs.

Ensure that the cables are of the appropriate rating for the required duty and are fastened to the correct terminal. Connection details can be found on the wiring diagram.

Cable Size: Power Terminals 1,2 and 3: Max 6 mm²

PE connection: Max 6 mm²

Control contacts: (4 - 50) Max 2.5 mm²

8. Operating Your Actuator

8.1 Operating by Hand

⚠ CAUTION: Under no circumstances should any additional lever device such as a wheel-key or wrench be applied to the handwheel in order to develop more force when closing or opening the valve as this may cause damage to the valve and/or actuator or may cause the valve to become stuck in the seated/backseated position.

Keep clear of the handwheel when engaging hand operation. Actuators driving valves via extension shafts may be subject to retained shaft torsion which can cause the handwheel to rotate when hand operation is engaged.

To engage handwheel drive depress the Hand/Auto lever into "Hand" position and turn the handwheel to engage the clutch. The lever can now be released, it will return to its original position. The handwheel will remain engaged until the actuator is operated electrically when it will automatically disengage and return to motor drive.

For local lockout purposes the Hand/Auto lever can be locked in either position using a padlock with a 6.5 mm hasp.

Locking the lever in the "hand" position prevents electrical movement.

8.2 Operating Electrically

⚠ CAUTION: Electrical operation is only permitted once the actuator is fully commissioned to the valve. Operating electrically before commissioning could result in damage to the actuator and/or valve.

Electrical motor operation has priority over hand operation. The motor drive will automatically re-engage after hand operation has occurred unless the hand/auto lever is held in the engaged position.

Electrical operation is possible with external controls or using the local controls included with the Atronik or Centronik control module (if fitted). CKQ Standard (without control Modules), when connected through customer control system time delay to switch off the actuator should be <100ms.


9. Commissioning

9.1 Atronik Interface

- A Status Indication
- B Open
- C Close
- D Remote
- E Stop
- F Local



- A Open Limit
- B Close Limit
- C Intermediate Travel
- D Fault Condition




9. Commissioning

9.2 Centronik Interface

- A IrCK Transmitter / Receiver
- B Open
- C Close
- D Remote
- E Stop
- F Local



- A Bluetooth® Connection
- B Infrared Connection
- C Configuration Mode
- D Communication Feedback
- E Valve Position
- F Current Menu
- G Sub Menu / Setting Value



9. Commissioning

9.3 Centronik Navigation

The Centronik Control Module can be configured using two different input methods. An optional Bluetooth Setting Tool provides a handheld solution compatible with Infrared or optional Bluetooth communication. Alternatively the local selector knobs can be used to navigate in the same way. Be sure to read and understand the equivalent input commands. Instructions included in this manual are provided as shorthand symbols shown below.

9.3.1 Local Selector input



9.3.2 Setting Tool Input



Navigate to previous item within the current menu / decrease value / toggle setting



Exit to previous menu / exit setting change



Navigate to next item within the current menu / increase value / toggle setting



Enter menu / confirm selection / edit setting / save setting value



9. Commissioning

9.4 Centronik Feedback

The Centronik display interface includes various features that provide feedback to the operator. This ensures that changes to the configuration of the actuator can be confirmed and validated during the commissioning process.

9.4.1 Arrow Identification

During general menu navigation, each submenu/setting will have a set of behaviour arrows associated with it. This lets the operator know what can be achieved on the current screen.

- ▣ ▣ Solid blocks on the setting indicate you are in viewing mode.
- ◀ ▶ Arrows on the setting/menu indicate navigation is possible - both directions.
- ◀ ▶ This indicates you are presently at the first menu choice or lowest setting value.
- ◀ ▶ This indicates you are presently at the last menu choice or highest setting value.
- ◀ ▶ This indicates the setting is read only or only has one possible value.

- ◀ Current Value ▶
- ◀ Both Directions ▶
- ◀ First Menu ▶
- ◀ Last Menu ▶
- ◀ Read Only ▶

9.4.2 Confirmation Feedback

Whilst modifying settings or navigating through the various Centronik interface menus, it is important to recognise that a change has been accepted or saved.

A small confirmation dot will be shown in the top right corner of the display if a valid input command has been recognised by the Centronik interface.

For each movement, the confirmation dot will only be shown once the Open/Close selector returns to the default rest position.



9. Commissioning

9.5 Basic Mechanical Switch Mechanism Setting

9.5.1 Instructions

⚠ WARNING: Isolate all power to the actuator unless explicitly instructed otherwise.

Remove the four M6 cap screws retaining the switch mechanism cover.

Note: Consult wiring to determine specification of switches fitted.

A 5mm Allen (Hex.) key and 0.8 x 4mm flat screwdriver are required to perform commissioning of the CKQ Mechanical Switch Mechanism.

⚠ CAUTION: For CKQ Standard actuators, the required end of travel action (torque or position) is determined by the set of switches cabled to the controlling switch gear - refer to actuator terminal plan and site field wiring.

⚠ CAUTION: For CKQA and CKQc actuators, the required end of travel action (torque or position) is determined by settings detailed in Section 9.6.




Set Torque Limits

- A Indicator/Adjustment Point
- B Torque Set Screw
- C Open Torque Adjustment Point
- D Close Torque Adjustment Point
- E Factory Calibration Fixings

⚠ CAUTION: Do not adjust the factory calibration fixings or position of the yellow torque indicator plates. These are factory configured and should not be removed under any circumstance.

- 1) Move the valve to a mid-travel position and loosen the Torque Set Screw 1.5 turns using a flat screwdriver.
- 2) Adjust each Torque Cam to the desired value - between min. (40%) & max. (100%) - by moving the Open/Close Torque Adjustment Point using a screwdriver.
- 3) Tighten the Torque Set Screw once both torque trip limits have been set.

⚠ CAUTION: Tighten the Torque Set Screw until the screw is fully tightened.



9. Commissioning

9.5.2 Set Position Limits

F CLS Adjustment Cam

G OLS Adjustment Cam


H Auxiliary Close Limit Switch (ACLS) Cam

I Auxiliary Open Limit Switch (AOLS) Cam

The following instructions are for clockwise to close actuators. OLS and CLS adjustment cams have the opposite functionality for anti-clockwise to close actuators.

⚠ CAUTION: The main power supply must be maintained during the commissioning process for CKQ, CKQA and CKQc actuators.

- 1) Move the actuator to the valve CLOSED position using the handwheel.
- 2) Press and hold the CLS/ACLS Adjustment Cam against the spring to allow free rotation of the cam.
- 3) Rotate the cam clockwise until the cam engages the switch. Release pressure against the spring to set the cam.
- 4) It is necessary to confirm the switch has engaged correctly.
 - a. For Standard actuators, measure across the appropriate terminals using a continuity meter – 12 and 13 for motor control and 14 and 15 for indication feedback.
 - b. For CKQA actuators fitted with an Atronik control module, confirm the closed limit status indicator is illuminated.
 - c. For CKQc actuators fitted with a Centronik control Module, confirm the position display shows the closed limit symbol.
- 5) Move the actuator to the valve OPEN position using the handwheel.
- 6) Press and hold the OLS/AOLS Adjustment Cam against the spring to allow free rotation of the cam.
- 7) Rotate the cam anti-clockwise until the cam engages the switch. Release pressure against the spring to set the cam.
- 8) It is necessary to confirm the switch has engaged correctly.
 - a. For CKQ Standard actuators, measure across the appropriate terminals using a continuity meter – 16 and 17 for motor control and 18 and 19 for indication feedback.
 - b. For CKQA actuators fitted with an Atronik control module, confirm the open limit status indicator is illuminated.
 - c. For CKQc actuators fitted with a Centronik control module, confirm the position display shows the open limit symbol.



Atronik close limit indication.



Centronik close limit indication.



Atronik open limit indication.




Centronik open limit indication.

9. Commissioning

9.6 End of Travel Action

9.6.1 Atronik

For CKQA actuators, the required end of travel action (torque or position) is determined by 'OPEN ACTION' and 'CLOSE ACTION' DIP switch settings as shown below.



9.6.2 DIP switch functions


Label	Function	OFF	ON
ESD FUNCTION A	ESD Action	A OFF and B OFF = Disabled A ON and B OFF = Open	A ON and B ON = Stay put A OFF and B ON = Close
ESD FUNCTION B			
ESD NC/NO	ESD Contact Form	ESD active when signal applied (normally open)	ESD active when signal removed (normally closed)
PTR LOCAL	Local Control	Local control is maintained	Local control is push-to-run
CLOSE DIRECTION	Direction	Clockwise to close	Anti-clockwise to close
PRIORITY A	2-Wire Priority	A OFF and B OFF = Close Priority A ON and B OFF = No Priority	A ON and B ON = Open Priority A OFF and B ON = No Priority
PRIORITY B			
OPEN ACTION	Open Action	Stop on position limit	Stop on torque limit
CLOSE ACTION	Close Action	Stop on position limit	Stop on torque limit
LED	LED	Green = Close Red = Open	Red = Close Green = Open
STD/OPT CONTROL	Control Source	Hardwired control only	Option control only
POWER	Power	3-phase power supply	Not applicable
RELAY A	Relay Conditions	Relay settings are determine by a combination of A, B and C. Refer to PUB111-110 for relay setting information.	
RELAY B			
RELAY C			
SETUP	Actuator speed*	Stroke time < 45 seconds	Stroke time ≥ 45 seconds

*SETUP switch does not alter actuator output speed.

9. Commissioning

9.6.3 Centronik

For CKQc actuators fitted with a Mechanical Switch Mechanism, the required end of travel action (torque or position) is determined by the **[ACTION]** setting within the Centronik configuration. All other limit functions will not be available as they need to be intrusively set on the mechanism.





9.7 Centronik Setting Adjustment

9.7.1 Entering Configuration mode

Access to configuration mode will vary depending on the navigation method employed. To access configuration mode with the local selector, ensure the actuator is in Stop mode and input the following sequence:



Each command input must be completed within one second of the last and the selector knob must return to its default rest position between each input.

To access configuration mode with the Bluetooth Setting Tool, ensure the actuator is in Stop mode and point the setting tool directly at the IrCK LED.

Press to initiate communication. The IrCK symbol will be shown when an input from the Bluetooth Setting Tool is registered by the Centronik Control Module.

If the optional Bluetooth module is fitted, the Setting Tool will begin communication through IrCK until a secure Bluetooth link has been established. To confirm a Bluetooth connection has been successful, the top left symbol on the Centronik display will change from IrCK to and the Bluetooth Setting Tool button will illuminate solid blue.

For IrCK communication, the Bluetooth Setting Tool must be aligned to the IrCK LED at all times.



9.7.2 Entering the User Password

The password entry screen will be displayed with the default password visible. Press to confirm this entry or use to enter a different password. For instruction on changing the user password, refer to PUB111-005.

Blank spaces will fill with whilst modifying the password text.

Once a valid password has been entered the display will show the current active permission level with a symbol and text.

Press to return to the main menu.

Actuator settings cannot be modified in Remote.

The symbol shown to the left side of the display will reference the following permission levels:

- User level permission to provide basic access to settings for commissioning and configuration purposes.
- Super User level permission to provide access to more advanced setting features.
- Service level permission for engineer access only.

9. Commissioning

9.8 Secondary Function Setting

CKQ range actuators can be supplied with optional add-ons that provide extra functionality. For instruction on setting secondary functions, please refer to the following documents available on www.rotork.com

CKQA – refer to PUB111-110

CKQc – refer to PUB111-004

10. Maintenance, Monitoring and Troubleshooting

Routine Maintenance should include the following :

- Check actuator to valve fixing bolts for tightness
- Ensure valve stems and drive nuts are clean and properly lubricated
- If the motorised valve is rarely operated, a schedule of operation should be set up
- Check the actuator for damage, loose or missing fixings
- Ensure that there is not an excessive build up of dust or contaminate on the actuator

11. Disposal / Recycling

User advice on disposal of your product at the end of its life. Please see table below. In all cases check local authority regulation before disposal.

Oil:

Actuators are factory filled with ELFMATIC G2 / AUTO TRANSFLUID DEXRON III oil suitable for ambient temperatures ranging from -30 to +70 °C (-22 to +158 °F)

Base assembly:

O-rings grease: SERVOGEM / ELF LEX2 / GULF CROWN MP or equivalent for all temperature ranges.

The actuator can be removed by reversing the operations detailed in the mounting and cabling sections. All warnings as detailed in the mounting and cable connection sections must be followed. Disposal of the actuator or any of its components should be done in accordance with the table below.

⚠ WARNING: It is essential that the actuator is not subject to any valve / system loads at the time of removal as this could cause operator injury due to the actuator moving unexpectedly.

12. Environmental

Standard CKQ actuators are suitable for applications where vibration and shock severity does not exceed the following:

Plant Induced Vibration: 1g rms total for all vibration within the frequency range of 4 to 1000 Hz

Shock: 5g peak acceleration

Watertight: IP68 IEC 60529 (8 metres for 96 hours)

Temperature: -30 to +70 °C (-22 to +158 °F)

EMC: The equipment is intended for use in an industrial electromagnetic environment.

Subject	Definition	Remarks / examples	Hazardous	Recyclable	EU Waste Code	Disposal
Electrical & Electronic	Printed circuit boards	All products	Yes	Yes	20 01 35	Use specialist recyclers
	Wire	All products	Yes	Yes	17 04 10	
Metals	Aluminium	Gearcases and covers	No	Yes	17 04 02	Use licensed recyclers
	Copper/Brass	Wire, gears, motor windings	No	Yes	17 04 01	
	Zinc	CKQ clutch ring and associated components	No	Yes	17 04 04	
	Iron/Steel	Gears and bases	No	Yes	17 04 05	
	Mixed Metals	CKQ motor rotors	No	Yes	17 04 07	
Plastics	Glass filled nylon	Electronics chassis	No	No	17 02 04	Disposal as general commercial waste
	Unfilled	Gears, window, blanking plug	No	Yes	17 02 03	Use specialist recyclers
Oil /Grease	Mineral	Gearbox lubrication	Yes	Yes	13 02 04	Will require special treatment before disposal, use specialist recyclers or waste disposal companies
	Grease	Handwheel	Yes	No	13 02 08	
Rubber	Seals & O-rings	Cover and shaft sealing	Yes	No	16 01 99	May require special treatment before disposal, use specialist waste disposal companies

13. Components of The Modular CKQ Actuator Design

1 Atronik module



The Atronik control module provides the user with simple, robust valve control and clear valve status indication

- 1a LED status indication display plus non-intrusive local controls
- 1b Plug and Socket connection
- 1c Double-sealing water and dust ingress protection

2 Centronik module



The Centronik control module provides the user with comprehensive intelligent valve control, detailed data logging and asset management

- 2a Multilingual display plus non-intrusive local controls
- 2b Plug and Socket connection
- 2c Double-sealing water and dust ingress protection
- 2d Up to two extra option cards

3 Standardised motor module



Motor modules utilise the same connection method across all speeds for each size CKQ

4 Manual handwheel



Independent manual override for emergency operation

5 Double-sealing water and dust ingress protection



Proven double sealing arrangement to maintain IP68 (8 m for 96 hours) protection

6 Mechanical switch mechanism (MSM)



Cam engaged position and torque switches with reduction gearing for extended travel

7 Local indication cover






Rotate through 360° in 90° increments to suit installation in any orientation



8 Rotork Bluetooth® Setting Tool Pro



View, adjust and extract data from Centronik control modules

Module Compatibility Chart

Symbol	Actuator
	CKQ - no control module
	CKQA - Atronik control module
	CKQc - Centronik control module



rotork®



www.rotork.com

A full listing of our worldwide sales and service network is available on our website.

Rotork plc
Brassmill Lane, Bath, UK
tel +44 (0)1225 733200
email mail@rotork.com

PUB111-131-00
Issue 08/22

As part of a process of on-going product development, Rotork reserves the right to amend and change specifications without prior notice. Published data may be subject to change. For the very latest version release, visit our website at www.rotork.com

The name Rotork is a registered trademark. Rotork recognises all registered trademarks. Published and produced in the UK by Rotork. POLJB0822