

Keeping the World Flowing for Future Generations

Cl Series Chain Wheels Installation Instructions

Models: CL6, CL7.5, CL9, CL12, CL15, CL18, CL21, CL24 & CL30

Procedure:

- 1. Place U-Strap (E) over rim of valve handwheel. Open side of U-Strap should face the center of the chain wheel
- 2. Place Sprocket (A) against front of handwheel. Align one Slot (D) with holes in U-Strap and insert Bolt (F) through both the slot and holes in the strap.
- 3. Attach Lock Washer & Nut (G) and hand tighten.
- 4. Repeat procedures 1, 2 and 3 on each of the two remaining straps.
- 5. Centre the Sprocket and tighten all nuts securely.

A. Sprocket E. U-Straps (3) B. Set Collar G. Lock Washers & C. Chain Guide Nuts (3 Sets) D. Slots (3)


See back for instructions on Model CL4

F. Carriage Bolts (3)



Caution:

To prevent the handwheel from backing off the stem, the Handwheel Retaining Nut MUST be secured with a Set Screw. In addition, it is strongly recommended that an appropriately sized Roto Hammer RCK Safety Cable Kit (optional) be installed on every overhead chain wheel operated valve. All chain wheel installations should be properly maintained and regularly inspected. Set screws and other threaded fasteners MUST be secure and tight.



A full listing of the Rotork sales and service network is available on our website.

www.rotork.com

Corporate Headquarters Rotork plc

+44 (0)1225 733200 tel mail@rotork.com email

Rotork Controls 3920 West Point Blvd Winston-Salem, NC 27103 tel 336 659-3400

email US-WS-CS@rotork.com

PUB148-006-00 Issue 12/23

rotork®

Keeping the World Flowing for Future Generations


CL Series Chain Wheels

Installation Instructions



Procedure:

- 1. Place Clamping Plate (E) over valve stem on back side of valve handwheel.
- Place Sprocket (A) against front side of valve handwheel. Insert Bolts (F) through Slots (C) and through matching slots in Clamping Plate. (For easy installation, slots keep carriage type bolts from turning.)
- Loosely attach Lock Washers & Nuts (G) to Bolts and center Sprocket on valve handwheel.
- 4. Tighten nuts securely.







Caution:

Provisions must be made to prevent the HANDWHEEL RETAINING NUT FROM BACKING OFF whenever a chain wheel is installed. To ensure safe operations, Roto Hammer recommends that thorough inspection of all chain operated valves be performed as a routine part of the user's Safety/Maintenance Schedule. Set screws and other threaded fasteners MUST be secure and tight.

In addition, it is strongly recommended that an appropriately sized Roto Hammer RCK Safety Cable Kit (optional) be installed on every overhead chain wheel operated valve.

- A. Sprocket
- B. Set Collar
- C. Slots
- D. Chain Guide
- E. Clamping Plate
- F. Carriage Bolts
- G. Lock Washers & Nuts (4 Sets)

See front for instructions on Models CL6, CL7.5, CL9, CL12, CL15, CL18, CL21, CL24 & CL30

A full listing of the Rotork sales and service network is available on our website.

www.rotork.com

Corporate Headquarters Rotork plc

tel +44 (0)1225 733200 email mail@rotork.com Rotork Controls 3920 West Point Blvd Winston-Salem, NC 27103

tel 336 659-3400 email US-WS-CS@rotork.com

PUB148-006-00 Issue 12/23