

# rotork®

Keeping the World Flowing  
for Future Generations

**ELC 400**  
**ELC 500**  
**ELC 1000**  
**ELC 1500**

Installation manual for ELC range  
linear electric actuators



CE

## Contents

Section	Page	Section	Page
<b>1. Safety</b>	<b>3</b>	<b>5. Commissioning</b>	<b>18</b>
1.1 Proper use	3	5.1 Operating parameters and coding switch positions	18
1.2 Information for the operator	3	5.2 Set input signal	19
1.3 Personnel	3	5.3 Set actuating time	19
1.4 Prior to starting work	4	5.3.1 ELC 400	19
1.5 During operation	4	5.3.2 ELC 500	19
<b>2. Product specification</b>	<b>5</b>	5.4 Set hysteresis	19
2.1 Components	5	5.5 Set actuating direction	20
2.1.1 Component parts ELC 400, ELC 500, ELC 1000, ELC 1500	5	5.6 Set autotest and autopause	20
2.2 Accessories	6	5.7 Set limit position	21
2.3 Operating modes	7	5.8 Set potential-free limit switch	21
2.3.1 Continuous mode	7	5.9 Initialise the path-measuring system	22
2.3.2 Three-point mode	7	5.10 Commissioning	22
2.4 Functions	7	<b>6. Operation</b>	<b>23</b>
2.4.1 Binary signal / frost protection function	7	6.1 Switching between manual and automatic modes	23
2.4.2 Lock detection	7	6.2 LED display	23
2.4.3 Internal temperature monitoring	7	<b>7. Maintenance, care and repairs</b>	<b>24</b>
2.4.4 Open-circuit detection	8	<b>8. Spare parts</b>	<b>24</b>
2.4.5 Actuating time	8	<b>9. Shutdown and disposal</b>	<b>25</b>
2.4.6 Hysteresis	8	<b>10. Troubleshooting</b>	<b>25</b>
2.4.7 Manual mode and feedback signal	8	10.1 Troubleshooting	25
2.4.8 Auto test	8	10.2 Operating faults checklist	26
2.4.9 Auto pause	8		
2.4.10 Potential-free limit switch (accessory)	8		
2.5 Technical data	9		
2.6 Rating plate	9		
<b>3. Transport and storage</b>	<b>10</b>		
<b>4. Assembly</b>	<b>10</b>		
4.1 Check the scope of supply	10		
4.2 Prepare for installation	11		
4.3 Mount linear actuator on valve	12		
4.3.1 Assembly of ELC 400, ELC 500, ELC 1000, ELC 1500	12		
4.4 Fit/remove cover	13		
4.5 Connect the electrics	14		
4.5.1 Control-independent switching	15		
4.5.2 Remove printed circuit board cover	15		
4.6 Accessories installation	16		
4.6.1 Limit switch printed circuit board installation	16		
4.6.2 Fit the printed circuit board for mA output signal.	16		

## 1. Safety

---

Read these operating instructions carefully particularly the following safety instructions prior to installation and operation.



CAUTION / NOTE / WARNING  
as indicated in the manual.

### 1.1 Proper use

ELC 400, ELC 500, ELC 1000 and ELC 1500 linear actuators are controlled by three-point control or constant control. Linear actuators in the series described in these operating instructions are used for valve stroke adjustment.

Compliance of the above type designation with the linear actuator rating plate must be checked prior to starting any operations in order to guarantee utilisation in accordance with specification. The data on the rating plate specifies the actuator technical details and mains power supply requirements.

It is the users' responsibility to ensure that the equipment is operated safely and that all staff working with or on the equipment are properly trained for the work they are performing and aware of their liabilities in terms of health and safety in the workplace. It is extremely important that precautions are taken to avoid spark or static discharge in any areas of potentially explosive atmosphere.

The intended use also includes the compliance with accident preventions, DIN VDE regulations and safe working practices for all measures described in these operating instructions in due consideration of prevailing rules.

The intended use also includes the compliance with accident preventions, DIN VDE regulations and safe working practices for all measures described in these operating instructions in due consideration of prevailing rules.

### 1.2 Information for the operator

Always keep the operating instructions available at the linear actuator deployment site.

Observe the current health and safety, accident prevention and DIN VDE standards for installation, operation and maintenance.

Take into consideration any additional regional, local or in-house safety regulations.

Ensure that every person entrusted with one of the tasks specified in these operating instructions has read and understood these instructions.

### 1.3 Personnel

Only qualified personnel may work on these linear actuators or in their vicinity. Qualified persons are those persons entrusted with installation, assembly, commissioning and operation or maintenance of the linear actuators and possessing the appropriate qualifications for their activity. The necessary and prescribed qualifications include:

- Training / instruction or authorisation to turn on / off circuits and appliances / systems according to EN 60204 (DIN VDE 0100 / 0113) and the standards of safety technology
- Training or instruction according to the standards of the safety technology concerning care and use of adequate safety and work protection equipment
- First aid training

Work in a safe manner and refrain from any working practice which endangers the safety of persons or damages the linear actuator or other assets in any way whatsoever.

## 1. Safety

---

### 1.4 Prior to starting work

Prior to starting any work, check that the type designations specified here concur with the data on the linear actuator rating plate.

Linear actuators ELC 400, ELC 500, ELC 1000, ELC 1500.

### 1.5 During operation

Safe operation is only possible if transportation, storage, installation, operation and maintenance are carried out according to the instructions in this manual and the applicable national and international standards.

#### **Transportation, installation and assembly**

Observe the general set-up and safety regulations for heating, ventilation, air-conditioning and pipework design. Use tools correctly. Wear the necessary personal protection safety equipment.

#### **Repairs and maintenance**

Ensure that qualified personnel switch off the linear actuator prior to maintenance or repair work in accordance with DIN VDE.

## 2. Product specification

The linear actuator controls a step motor with the aid of a microcontroller. The rotational motion of the step motor is transformed into a linear motion via a planetary gearbox and a leadscrew with spindle nut.

### 2.1 Components

#### 2.1.1 Component parts ELC 400, ELC 500, ELC 1000, ELC 1500




Fig 2.1 Component drawings


ITEM	DESCRIPTION
1	Actuator casing
2	Crossbeam (optional)
3	Coupling piece*
4	Union nut
5	Spindle nut
8	Position display*
10	Protective tube
11	Spacer sleeve
13	Bridge
16	Gear casing
33	Sheeting
34	Knob
36	Handwheel
47	Viewing window

ITEM	DESCRIPTION
60	Guide bush
101	Engine/motor
107	Terminal board for 24 V or 230 V
110	Main board
201	Cover for 24 V or 230 V*
230	Cable inlet M20 × 1.5*
231	Cable inlet M16 × 1.5*
312	Safety disk
314	Blank flange*
315	Bolt*
452	Hexagonal nut M12*
480	Type plate
481	Circuit diagram on cover

\* This component part is available as a spare part.


## 2. Product specification

### 2.2 Accessories



111 Printed circuit board for output signal X=0/4 to 20 mA

Fig 2.2 Printed circuit board for mA output signal on the motherboard



106 Limit switch printed circuit board

Fig 2.3 Limit switch printed circuit board in cover

## 2. Product specification

### 2.3 Operating modes

The linear actuator can be operated in manual or automatic mode.

- The lift is adjusted via the handwheel in manual mode.
- The lift is electrically controlled in automatic mode.

#### 2.3.1 Continuous mode

In continuous mode the position of the linear actuator is specified by the system control. The input signal (Y) from the system control in the linear actuator is continually compared with the output signal (X) from the linear actuator for this purpose. The output signal is dependent on the position of the linear actuator (travel) in this instance.

The linear actuator moves until the input signal and the output signal correspond.

#### Input signal (Y)

The input signal (Y) from the system control specifies the reference position for the linear actuator. It is an analogue signal on terminal Y.

The following input signals are possible:

- 0 to 10 VDC / 2 to 10 VDC
- 0 to 20 mA / 4 to 20 mA

#### Output signal (X)

The output signal (X) specifies the actual position of the linear actuator. It is an analogue signal on terminal X.

0% to 100% valve lift is output as:

- 0 to 10 VDC
- 0 to 20 mA or 4 to 20 mA (Printed circuit board for output signal as optional extra (111))  
When using the option "Output signal (X) as current output (0/4 to 20mA)", deviations of the output signal (X) up to max. 5% to the input signal (Y) may occur in the medium stroke range. This deviation is due to the design and does not represent a defect.

#### 2.3.2 Three-point mode

The direction of movement is specified via a control voltage on terminal 2 and terminal 3 on the motherboard:

- If the control voltage on terminal 2 is on, the spindle nut extends
- If the control voltage on terminal 3 is on, the spindle nut retracts

### 2.4 Functions

#### 2.4.1 Binary signal / frost protection function

Terminals B1 and B2 on the motherboard are bridged in normal mode. If the circuit between B1 and B2 is broken, the linear actuator stores the actual position and then moves automatically to its limit position.

All other control signals are ignored during this process.

The linear actuator remains in the limit position until the circuit between B1 and B2 is closed again.

- In three-point mode the linear actuator then returns automatically to the stored position
- In continuous mode the reference value of the input signal is again approached

#### 2.4.2 Lock detection

If the linear actuator becomes mechanically locked, it returns briefly and tries again to reach the required position. If this does not happen after a total of 7 attempts, the linear actuator is switched off to avoid damage to linear actuator and actuator.

The lock detection is displayed via the green LED in the (47) viewing window.

See Table 7.

#### 2.4.3 Internal temperature monitoring

The actuator has internal temperature monitoring.

Overheating protection If the temperature in the actuator casing exceeds a limit value, the motor will be switched off. Once the motor has cooled down, it is automatically switched on again.

#### Actuator heating

If the temperature in the actuator drops below 15 °C, the motor is switched to heating in the operating pauses. The actuator heating switches off automatically at a constant temperature of approx. 22 °C. The actuator heating does not affect the functions of the actuator.

Heating capacity:

- 12.5 W at temperatures from approx. 8 °C to approx. 15 °C
- 18 W at temperatures below 8 °C

The heating prevents the build-up of water condensation in the actuator and at the same time guarantees the smooth running of the gears even at temperatures up to approx. -10 °C.

Heating operation and motor switch-off are displayed via the LED in the (47) viewing window.

See Table 8, Red LED display.

## 2. Product specification

---

### 2.4.4 Open-circuit detection

Open-circuit detection is only available in Continuous mode with an input signal 2 to 10 VDC and 4 to 20 mA.

If the input signal drops below 1 V or 2 mA in continuous mode, the linear actuator moves to the limit position set by coding switch S7.

Open-circuit detection is displayed via the green LED in the (47) viewing window.

See Table 7, Green LED display.

### 2.4.5 Actuating time

The time the spindle nut takes to travel a defined path, is called actuating time. The actuating time is indicated in s/mm. The actuating time is set by coding switch S5 (except for model ELC 1000, ELC 1500).

See Section 5.3, Set actuating time.

### 2.4.6 Hysteresis

The differential of the input signal (Y) required after a reversal of the signal direction so that the spindle nut is moved, is called hysteresis.

It is used to avoid permanent oscillation of the actuator motor around a specific lift position in the event of slight input signal changes.

See Section 5.4, Set hysteresis.

### 2.4.7 Manual mode and feedback signal

The lift can be manually changed in manual mode without power supply.

- The electronic motor and control are switched off in manual mode so that lift movements by the control are not possible
- As soon as the linear actuator is switched to manual mode, the control switches a signal to Terminal R, if the power supply is on

See Section 6.1, Switching between manual and automatic modes.

### 2.4.8 Auto test

If a valve is not actuated over a long period, the valve cone may seize. The Autotest function prevents this. If the Autotest function of the linear actuator is switched on, the linear actuator moves after approx. 10 days without actuation automatically in rapid traverse to the limit position set by coding switch S7 and returns to the starting position.

See Section 5.6, Set Autotest and Autopause.

### 2.4.9 Auto pause

The actuator uses this function to count the actuator commands which mean a change in direction. In the event of more than 20 different directional actuator commands per minute, a compulsory pause of 3 s is imposed.

See Section 5.6, Set Autotest and Autopause.

### 2.4.10 Potential-free limit switch (accessory)

The optional limit switch printed circuit board (106) can be used to set two lift positions at which a potential-free electrical contact is opened or closed.

See Section 5.8, Set potential-free limit switch.



## 2. Product specification

### 2.5 Technical data

Type	ELC 400/24, ELC 500/24, ELC 1000/24, ELC 1500/24	ELC 400/230, ELC 500/230, ELC 1000/230, ELC 1500/230
Supply voltage	24 VAC $\pm$ 10% 24 VDC $\pm$ 10%	115 VAC $\pm$ 10% 230 VAC $\pm$ 10%
Power consumption	ELC 400, ELC 1000, ELC 1500 = max. 50 VA ELC 500 = max. 18 VA	ELC 400, ELC 1000, ELC 1500 = max. 63 VA ELC 500 = max. 25 VA
Weight	ELC 400 = 9.2 kg ELC 500 = 7 kg ELC 1000 = 10.5 kg ELC 1500, ELC 1003 = 11 kg	ELC 400 = 9.6 kg ELC 500 = 8.2 kg ELC 1000 = 10.9 kg ELC 1500, ELC 1003 = 11.4 kg
Dimensions	See technical data sheets	
Stroke	max. 60 mm	max. 60 mm
Frequency	50/60 Hz $\pm$ 5%	50/60 Hz $\pm$ 5%
Ambient temperature	0 to +60°C	0 to +60°C
Enclosure protection	IP 54	IP 54
Operating mode	ELC 400, ELC 1000, ELC 1500 = S3 ED 30% ELC 500 = S3 ED 50%	
Actuating time	ELC 400 = 0.4 or 0.6 s/mm ELC 500 = 2.5 or 5 s/mm ELC 1000 = 1.0 s/mm ELC 1500 = 2.0 s/mm	ELC 400 = 0.4 or 0.6 s/mm ELC 500 = 2.5 or 5 s/mm ELC 1000 = 1.0 s/mm ELC 1500 = 2.0 s/mm
Actuating force	ELC 400 = 4 kN ELC 500 = 5 kN ELC 1000 = 10.0 kN ELC 1500 = 15.0 kN	ELC 400 = 4 kN ELC 500 = 5 kN ELC 1000 = 10.0 kN ELC 1500 = 15.0 kN

Table 1 Technical data

Input signal Y / Input resistor (resistance of load)	0 to 10 VDC / 77 k $\Omega$ 2 to 10 VDC / 77 k $\Omega$ 0 to 20 mA / 510 $\Omega$ 4 to 20 mA / 510 $\Omega$
Output signal X / Load capacity	0 to 10 VDC / resistance of load $\geq$ 1200 $\Omega$ , $I_{max}$ 8 mA 0 to 20 mA / resistance of load $\leq$ 500 $\Omega$ - with printed circuit board for output signal as optional extra (111) 4 to 20 mA / resistance of load $\leq$ 500 $\Omega$ - with printed circuit board for output signal as accessory (111)
Feedback signal R / Load capacity	24 VDC / minimum resistance $\geq$ 480 $\Omega$ , $I_{max}$ 35 mA
Transmission resistance between B1 and B2	max. 10 $\Omega$

Table 2 Technical data signals

### 2.6 Rating plate

The rating plate is located on the linear actuator casing.

This includes the type designation and the fabrication number (F.No.) with the date of manufacture (last four digits).

See Section 2.1, Components.


		
<b>ELC500/60-0000-0</b>		
F.-Nr.: 07204142/01/0607		
AC 50 Hz 230 V	max. 25 VA	5 kN
Y=0 to 10 VDC	IP 54	5 s/mm
X=0 to 10 VDC	S3-50% ED	Stroke 60 mm

Fig 2.9 Example of type plate

### 3. Transport and storage

---

#### CAUTION

**Risk of injury in the event of non-compliance with safety regulations.**

- **WEAR THE NECESSARY PERSONAL AND OTHER SAFETY EQUIPMENT**
- Avoid knocks, shocks, vibrations and similar to the linear actuator
- Store the linear actuator (and if necessary the complete actuating unit) in a dry place
- Observe the transportation and storage temperature of -20 to +65 °C.

### 4. Assembly

---

Prior to installation of the linear actuator:

*See Section 4.1, Check the scope of supply.*

*See Section 4.2, Prepare for installation.*

Installation of the linear actuator includes the following tasks:

*See Section 4.3, Mount linear actuator on valve.*

*See Section 4.4, Fit/remove cover.*

*See Section 4.5, Connect the electrics.*

#### 4.1 Check the scope of supply

- 1 Check the packaging for damage.
- 2 Dispose of the packaging in an environmentally friendly manner.
- 3 Check against the delivery note that the delivery is complete.
- 4 Report any missing or damaged products to the manufacturer.

## 4. Assembly

### 4.2 Prepare for installation

#### ⚠ NOTE

Malfunction due to exceeding the stroke range.

If the stroke range of the valve exceeds the stroke range of the linear actuator, the linear actuator will malfunction.

Ensure there is stroke limitation in the valve.

#### ⚠ NOTE

Damage due to valve not being fitted.

If the linear actuator is operated without valve, then the spindle nut may fall out due to the missing stop. Therefore, only operate the linear actuator with a valve fitted.

- 1 Ensure that there is space of approx. 200 mm above the cover at the installation site.
- 2 Check the working environment prior to fitting the linear actuator and commissioning.
- 3 Ensure that the valve is fitted correctly.  
*See Valve installation instructions for further information.*
- 4 Determine the installation position of the linear actuator.  
Linear actuators may not be installed in a suspended position.




Fig 4.4 Installation positions for linear actuator and valve

## 4. Assembly

### 4.3 Mount linear actuator on valve

If the linear actuator and the valve are supplied separately, you must mount the linear actuator on the valve.

#### 4.3.1 Assembly of ELC 400, ELC 500, ELC 1000, ELC 1500




Fig 4.5 Mounting the linear actuator on the valve

ITEM	DESCRIPTION
2	Crossbeam
3	Coupling piece
5	Spindle nut
18	Valve stem
19	Valve neck
36	Handwheel

ITEM	DESCRIPTION
312	Lock washers
314	Blank
315	Bolt
451	Hexagon nut M10/M14
452	Hexagonal nut
459	Hexagonal nut

## 4. Assembly

### Proceed as follows to install the linear actuator

- 1 Remove the blank (314) flange.  
*See Fig 4.5.*
- 2 Remove the bolt (315) from the coupling (3) or force it out.
- 3 Rotate the hexagonal nut M10 (451) wrench size 17 onto the valve spindle (18).
- 4 Rotate the coupling (3) onto the valve spindle (18).
- 5 Use the flat hexagonal nut to lock the valve spindle (18) to secure it against distortion.
- 6 Place the actuator with traverse (2) onto the valve neck (19).
- 7 Fix the crossbeam (2) using a hexagon nut (459) spanner width 50 / 60.
- 8 Use the handwheel (36) to adjust the spindle nut (5) upwards so that the bolt (315) can be refitted.
- 9 Fit the blank (314) flange.

### Proceed as follows to dismantle the linear actuator

- 1 Carry out the installation sequence steps in reverse order.

### 4.4 Fit/remove cover

The terminals for the electrical connection are located in the cover.

#### WARNING

##### Electric shock due to live components.

If the power supply is switched off, there is danger of electric shock due to live components.

- Prior to starting work ensure that the actuator is disconnected safely from the mains power supply.
- Secure against unauthorised switching-on.
- Remove the cover only temporarily.

### Proceed as follows to remove the cover

- 1 Unlock the cover (201). Use a screwdriver (34) to turn the rotary knob counterclockwise through 90° as far as the stop.




Fig 4.6 Remove cover


- 2 Insert a screwdriver into a groove in the cover and lift off the cover (201).

#### NOTE

##### Damage to the equipment due to damaged wiring.

**When removing the cover it is possible to tear or damage the wiring in the cover. Remove the cover carefully.**

- 3 Remove the cover (201) carefully.
- 4 Disconnect the plug connection between motherboard (110) and cover (201).



- |  |                              |
|--|------------------------------|
| 27 Spacers                             | 115 Plug connector bush      |
| 106 Limit switch printed circuit board | 110 Main board               |
| 107 Terminal board for 24 V or 230 V*  | 201 Cover for 24 V or 230 V* |

Fig 4.7 Installation of the limit switch printed circuit board in the cover

### Proceed as follows to replace the cover

- 1 Insert the cables previously removed into the plug connector in the motherboard (110).

Take care not to damage the grooves in the plug connector and bush.

The cover (201) can be fitted in four different positions offset by 90° respectively. This enables convenient laying of the connecting cable in the event of different installations of the linear actuator.

- 2 Put the cover (201) on and press it into place with moderate application of force.
- 3 Check the correct fit of the cover to ensure the tightness of the actuator casing.
- 4 Lock the cover (201). Use a screwdriver (34) to turn the rotary knob clockwise through 90° as far as the stop.

## 4. Assembly

### 4.5 Connect the electrics

#### **⚠ WARNING**

##### **Danger of death if carried out by unqualified personnel.**

Connection of the electrics by unqualified personnel may cause death, serious physical injury or considerable material damage as a result.

- Ensure that this work is only carried out by qualified personnel

See Section 1.3, Personnel.

#### **⚠ WARNING**

##### **Electric shock due to live components.**

Once the power supply has been switched on, there is risk of electric shock due to live components.

- Prior to starting work ensure that the actuator is disconnected safely from the mains power supply.
- Secure against unauthorised switching-on.

##### **Proceed as follows to prepare for the power connection**

- 1 Ensure that the power supply concurs with the data on the linear actuator rating plate.
- 2 Design the cable profile in accordance with the actuator power and the necessary cable length in order to avoid operating faults.

- 3 Lay the mains cables for a power supply of > 48 V separately from the signal and control cables.

If the cables are laid in a common cable duct, screened control cables must be used.

- 4 Check the power supply voltage.

If the required tolerance of the power supply voltage cannot be maintained with a mains transformer, an AC voltage regulator must be used.

See Section 2.5 Technical data.

##### **Proceed as follows to switch the electrics on**

- 1 Remove the cover (201).

See *Proceed as follows to remove the cover.*

- 2 Feed the cable through the screw connector in the cover to the terminal strip.

- 3 Connect the electrics in accordance with the circuit diagram.

See Fig 4.8.

The circuit diagram (481) is located on the printed circuit board cover (33).

#### **⚠ NOTE**

##### **Malfunction due to incorrect zero potential.**

If the linear actuator is electrically supplied by signal generators with different zero potentials, this may cause incorrect dynamic performance.

- Ensure that the zero potentials are correctly used.

See Table 3.

- 4 Tighten the screw connections.




Fig 4.8 Wiring diagram

Terminal	Description
UB, N1	Supply voltage:
2	Control voltage for downward movement in three-point mode
3	Control voltage for upward movement in three-point mode
R	Feedback signal in "manual" mode • R= 24 VDC max. 35 mA
B1, B2	Binary input / frost protection function
N2	Zero potential for signals X, Y and R • If the zero potentials for signals X, Y and R are identical to the zero potential for the power supply, terminals N1 and N2 can be bridged. • If the actuator is operated in continuous mode at 230 V, N2 must be closed. • If the actuator is operated in three-point mode at 230 V, N2 must be closed, if X and R also need to be used.
Y	Input signal for continuous mode
X	Output signal for continuous mode
20, 21, 22	Terminals for limit switch unit WE1
23, 24, 25	Terminals for limit switch unit WE2

Table 3 Circuit diagram legend

## 4. Assembly

### 4.5.1 Control-independent switching

If operating with 24 V power supply and 0 to 10 VDC / 2 to 10 VDC input signal, the actuator can be switched to control-independent using the three-stage switch in the control cabinet.

#### Proceed as follows to switch the actuator to control-independent

- 1 Connect the 24 VAC power supply via a diode and a three-stage switch to terminal Y.




Fig 4.9 Control-independent switching

- 2 This switch can be used to move the linear actuator into the following positions:

- Control mode through input signal Y (normal mode)
- 10 V-Position
- 0 V-Position, at 2 to 10 VDC the linear actuator can be moved to the position selected by coding switch S7

See Section 5.1, Operating parameters and coding switch positions.

See Section 5.7, Set limit position.

### 4.5.2 Remove printed circuit board cover

The printed circuit board cover must be removed (33) first in order to adjust the linear actuator via the coding switches.

#### ⚠ WARNING

##### Electric shock due to live components.

If the power supply is switched off, there is danger of electric shock due to live components.

- Prior to starting work ensure that the actuator is disconnected safely from the mains power supply
- Secure against unauthorised switching-on

- 1 Insert a screwdriver into a groove in the cover (201) and lift the cover (201) out.
- 2 Insert a small screwdriver into the groove provided in the printed circuit board cover for this purpose (33) and remove it with care.




Fig 4.10 Remove the printed circuit board cover from the actuator casing

- 3 Once the printed circuit board cover (33) has been removed from the actuator casing (1 - see figure 2.1) coding switches S1 to S10 will be accessible.

## 4. Assembly

### 4.6 Accessories installation

Optional extras are only part of the scope of supply of the linear actuator if expressly ordered. The linear actuators are prepared for retrofitting the following:

- Printed circuit board for limit switch (106)
- Printed circuit board for output signal X=0/4 to 20 mA (111)

See Section 2.2, *Accessories*.

#### 4.6.1 Limit switch printed circuit board installation

##### **⚠ WARNING**

##### **Electric shock due to live components.**


If the power supply is switched off, there is danger of electric shock due to live components.

- Prior to starting work ensure that the actuator is disconnected safely from the mains power supply
- Secure against unauthorised switching-on

- 1 Open the linear actuator cover (201).

See Section 4.4, *Fit/remove cover*.


- 2 Press the limit switch printed circuit board (106) onto the terminal board (27) using the three spacers (107).



- |   |                                     |
|---|-------------------------------------|
| <b>27</b> Spacers                             | <b>115</b> Plug connector bush      |
| <b>106</b> Limit switch printed circuit board | <b>110</b> Main board               |
| <b>107</b> Terminal board for 24 V or 230 V   | <b>201</b> Cover for 24 V or 230 V* |

**Fig 4.11** Installation of the limit switch printed circuit board in the cover

- 3 Place the plug connector bush (115) for the limit switch printed circuit board (106) on the pin strip (123) on the (110) motherboard. Pay attention to the grooves in the pin strip and plug connector bush.



**123** Pin strip

**Fig 4.12** Pin strip for limit switch printed circuit board on the motherboard

- 4 Adjust the limit switch.

See Section 5.8, *Set potential-free limit switch*.

#### 4.6.2 Fit the printed circuit board for mA output signal.

##### **⚠ WARNING**

##### **Electric shock due to live components.**

If the power supply is switched off, there is danger of electric shock due to live components.

- Prior to starting work ensure that the actuator is disconnected safely from the mains power supply
- Secure against unauthorised switching-on

- 1 Open the cover (201) and remove the printed circuit board cover (481).


See Section 4.4, *Fit/remove cover*.

See Section 4.5.2, *Remove printed circuit board cover*.

- 2 Remove the jumper (JP1) from the motherboard (110).
- 3 Put the jumper (JP1) onto the plug-in bridge (113) for the printed circuit board for mA output signal.
- 4 Plug the printed circuit board for mA output signal (111) together with its pin strip into the plug-in bridge (113) on the motherboard (110).
- 5 Lock the spacers (27) into the holes in the motherboard.




## 4. Assembly



*Fig 4.13 Installation of the printed circuit board for mA output signal*

6 Select the output signal range with the jumper (JP1):

- Jumper right: 0 to 20 mA
- Jumper left: 4 to 20 mA



*Fig 4.14 Set signal range for mA output signal X*

## 5. Commissioning

### WARNING

#### Electric shock due to live components.


If the power supply is switched off, there is danger of electric shock due to live components.

- Prior to starting work ensure that the actuator is disconnected safely from the mains power supply
- Secure against unauthorised switching-on

The operating parameters are set (116) on the coding switches. The coding switches are located under the printed circuit board cover (33) in the actuator casing (1).

See Section 4.4, *Fit/remove cover*.

See Section 4.5.2, *Remove printed circuit board cover*.



33 Printed circuit board cover 116 Coding switch

Fig 5.1 Printed circuit board cover and coding switches

### 5.1 Operating parameters and coding switch positions

The operating parameters must be set with the coding switches before the linear actuator can be operated.

### NOTE

#### Malfunctions due to incorrect switch position S1.

Switch S1 must always be at "on".

- Ensure that switch S1 is at "on"





Switch	On			Off		
S1	Ready for operation			-		
S2	X characteristic curve			X characteristic curve		
S3	Y characteristic curve			Y characteristic curve		
S4	Input signal (Y) 0 to 10 VDC or 0 to 20 mA			Input signal (Y) 2 to 10 VDC or 4 to 20 mA		
S5	Actuating time ELC 400 0.4 s/mm	Actuating time ELC 500 2.5 s/mm	Actuating time ELC 1000, ELC 1500 no function, do not adjust	Actuating time ELC 400 0.6 s/mm	Actuating time ELC 500 5 s/mm	Actuating time ELC 1000, ELC 1500 no function, do not adjust
S6	Autotest and autopause on			Autotest and autopause off		
S7	Limit position for actuator spindle extended			Limit position for actuator spindle retracted		
S8, S9	The hysteresis (0.05 to 0.5 V) is set using S8 and S9					
S10	Input signal (Y) in mA			Input signal (Y) in V		

Table 4 Encoding switch and jumper settings

## 5. Commissioning

### 5.2 Set input signal




Fig 5.2 Set input signal

Further information: Input signal (Y).

### 5.3 Set actuating time

Further information: See Section 2.4.5, Actuating time.

#### 5.3.1 ELC 400




Fig 5.3 Set actuating time

#### 5.3.2 ELC 500




Fig 5.4 Set actuating time

### 5.4 Set hysteresis




Fig 5.5 Set hysteresis

For further information see Section 2.4.6, Hysteresis.

## 5. Commissioning

### 5.5 Set actuating direction

The actuating direction of the linear actuator can be reversed at the coding switch (inverted operation).















Actuator position	Normal operation	Inverted operation (X and Y inverted)
	 Y = 10 VDC  Y = 20 mA	 Y = 0 VDC  Y = 2 VDC  Y = 0 mA  Y = 4 mA
	 Y = 0 VDC  Y = 2 VDC  Y = 0 mA  Y = 4 mA	 Y = 10 VDC  Y = 20 mA
Coding switch S2: X (output signal), coding switch S3: Y (input signal)		

Table 5 Set actuating direction

### 5.6 Set autotest and autopause

If coding switch S6 is at ON, autotest and autopause are active.

Approaching the limit switch in rapid traverse is triggered approx. every 10 days in autotest. A new zero balance is carried out automatically.

A 3-second pause (2-minute measuring cycle) is carried out in autopause after more than 20 actuator commands in different directions per minute.

It is not possible to select these two functions separately.

## 5. Commissioning

### 5.7 Set limit position

Select the limit position for the linear actuator using coding switch S7:

- S7 ON: Limit position with extended spindle nut
- S7 OFF: Limit position with retracted spindle nut

The limit position is approached in the following situations:

- In the event of open-circuit detection by the Y signal (only for 2 to 10 V DC or 4 to 20 mA)
- In the event of a binary signal (circuit is broken between terminals B1 and B2)
- In autotest
- Upon disruption of the power supply (manual adjustment)

### 5.8 Set potential-free limit switch

Set the two limit switches via trimmer potentiometers P1/ P2 independently from one another. Carry out the specified working steps for each limit switch once.

#### Proceed as follows to set a limit switch

- 1 Ensure that the linear actuator has been started up and initialised.

See Section 5.10, *Commissioning*.

See Section 5.9, *Initialising the path-measuring system*.

#### NOTE

##### Malfunction due to inaccurately set limit switch.

If the actuator has been set to manual mode (without power supply), the limit switch can only be set inaccurately (centre position of the arm corresponds to the switching point for approx. 50% lift in this instance).

- Switch the actuator to automatic mode in order to set the limit switch accurately
- 2 Move the actuator into a position where a switching event should be triggered.

The following working steps must be carried out with the power supply switched on.

#### WARNING

##### Electric shock due to live components.

Once the power supply has been switched on, there is risk of electric shock due to live components.

- Take care not to touch any live components
- Take care not to cause a short circuit on a printed circuit board with the tool

- 3 Open the cover (201).

See Section 4.4, *Fit/remove cover*.

The limit switch printed circuit board is located in the cover (106).

- 4 Use a screwdriver to turn the trimmer potentiometer until the limit switch switches. The associated LED goes on or off during this operation.

Use potentiometer P1 (105 P1) to set limit switch 1.

LED 1 indicates the switching status.

Use potentiometer P2 (105 P2) to set limit switch 2.

LED 2 indicates the switching status.




Fig 5.6 Limit switch printed circuit board in cover

- 5 Observe the permitted limit switch contact load:

Nominal load	8 A, 250 VAC 8 A, 30 VDC
Switching voltage	max. 400 VAC max. 125 VDC

Table 6 Limit switch contact load

- 6 Switch off the power supply to the actuator and connect the limit switch contacts.
- 7 Close the linear actuator (201) cover.

See *Proceed as follows to replace the cover*.

## 5. Commissioning

### 5.9 Initialise the path-measuring system

#### NOTE

##### **Linear actuator starts automatically.**

Immediately upon connecting the power supply, the linear actuator moves automatically to a path-measuring system reference point.

- Wait until the reference point has been reached and the linear actuator stops

The incremental path-measuring system must be initialised upon completion of the following tasks:

- In the event of initial start-up
- After repairs to the valve or the actuator
- After changing the valve or the actuator

The initialisation can be triggered in two ways.

##### **Proceed as follows to initialise via the initialising button**

#### WARNING

##### **Electric shock due to live components.**

Once the power supply has been switched on, there is risk of electric shock due to live components.


- Take care not to touch any live components
- Take care not to cause a short circuit on a printed circuit board with the tool

- 1 Open the cover (201).

*See Section 4.4, Fit/remove cover.*

- 2 Ensure that the power supply is on.

- 3 Press the initialising button (118) and keep it depressed for at least 1 second.



**110** Main board

**118** Initialising button

*Fig 5.7 Initialise the path-measuring system*

### 5.10 Commissioning

- 1 Check that all installation and assembly tasks have been completed correctly.

*See Section 4, Assembly.*

- 2 Ensure that the electric actuation of the linear actuator is ensured without danger to persons or equipment or the system.

- 3 Ensure that the linear actuator is correctly fixed and the linear actuator cover is closed.

*See Section 4.4, Fit/remove cover.*

- 4 Ensure that the linear actuator is switched to automatic mode.

*See Section 6.1, Switching between manual and automatic modes.*

- 5 Ensure that the operating parameters have been correctly set.

*See Section 5.1, Operating parameters and coding switch positions.*

- 6 Ensure that the path-measuring system has been initialised.

*See Section 5.9, Initialise the path-measuring system.*

- 7 Connect the power supply. Then the linear actuator moves to the reference point.

The linear actuator is ready for operation.

## 6. Operation

Before the linear actuator can be operated, it must be initialised and the operating mode selected.


See Section 5, Commissioning.

See Section 5.9, Initialise the path-measuring system.

### 6.1 Switching between manual and automatic modes

The linear actuator can be operated in automatic mode or in manual mode (manual adjustment).

- In automatic mode the spindle nut moves into the position specified by the control
- In manual mode the spindle can be adjusted manually, e.g. for inspection purposes. The output signal (X) is not available in manual mode



36 Handwheel

Fig 6.8 Select automatic mode

#### Proceed as follows to switch to manual mode

- 1 Move the handwheel (36) into the manual mode position and rotate it until the handwheel locks.

#### NOTE

##### Risk of damage to valve and actuator in manual mode.

The valve can get damaged if it is pressed too firmly into its seat when closing in manual mode.

- Do not rotate the handwheel any further if the amount of effort needs to be increased
- Never use force

- 2 Use the handwheel to rotate the spindle nut into the required position. Rotate the handwheel until the rotational resistance increases. Do not use force.

#### Proceed as follows to switch to automatic mode

- 1 Move the handwheel (36) into the automatic mode position.
- 2 The linear actuator moves first of all into the position specified by coding switch S7 and then into the position specified by the control.

### 6.2 LED display

The LEDs in the viewing window (47) indicate operating states or faults.

See Section 10.2, Operating faults checklist


















Green LED	Operating status / fault
 Duration 0.5s	<b>Normal operation, standby</b> The LED illuminates continuously, actuator awaits drive command.
    0.5s 0.5s 0.5s 0.5s	<b>Standard operation</b> Actuator carries out drive command.
    0.2s 1.5s 0.2s 1.5s Short – long rhythm	<b>Open-circuit detection</b> In operating modes 2 to 10 VDC or 4 to 20 mA, the input signal has dropped below 1 V or below 2 mA. See Section 2.4.4, Open-circuit detection.
    2.5s 2.5s 2.5s 2.5s Long – long rhythm	<b>Lock detection (only in continuous mode)</b> The linear actuator is mechanically locked. See Section 2.4.2, Lock detection.
    1.5s 0.2s 1.5s 0.2s Long – short rhythm	<b>Continuous signal on terminal 2 and 3</b> An initialisation run starts in the event of simultaneous control signal on terminals 2 and 3 (max. 4 attempts). The linear actuator switches off automatically after 4 failed attempts.

Table 7 Green LED display







Red LED	Operating status / fault
 OFF	<b>Temperature within normal range</b>
 Duration	<b>Heating operation</b> See Actuator heating.
    0.25s 0.25s 0.25s 0.25s Flashes regularly	<b>Actuator overheats</b> See Overheating protection.

Table 8 Red LED display

## 7. Maintenance, care and repairs

---

The linear actuator requires only periodic maintenance. To ensure that the spindle is greased, drive the actuator to its end position once per day.

## 8. Spare parts

---

When ordering accessories and spare parts please quote the specifications engraved on the type plate of your linear actuator. The specifications on the type plate are standard for the technical data of linear actuators as well as the requirements for the public power supply.

### NOTE

#### **Damage to device caused by faulty spare parts.**

Spare parts must match the technical data specified by the manufacturer.

- Use genuine spare parts at all times

*See Section 2.1, Component parts.*

*See Section 2.2, Accessories.*



## 9. Shutdown and disposal

---

Dispose of the linear actuator in accordance with national regulations and legislation.

## 10. Troubleshooting

---

The path-measuring system needs to be re-initialised after troubleshooting.

*See Section 5.9, Initialise the path measuring system.*

### 10.1 Troubleshooting

If the linear actuator does not work perfectly, proceed as follows to eliminate the fault:

- 1 Check that the linear actuator was installed correctly.
- 2 Check the linear actuator settings and the rating plate data.
- 3 Eliminate the faults using the checklist.

*See Section 10.2, Operating faults checklist.*

- 4 If this fault still cannot be eliminated, contact the manufacturer.
- 5 Please quote the following for all queries and returning goods to the manufacturer:
  - F-No. (Fabrication No. = Contract No.)
  - Type designation
  - Power supply and frequency
  - Additional equipment
  - Error report
- 6 If the fault cannot be eliminated by the inquiry, the equipment can be returned to the manufacturer.

## 10. Troubleshooting

### 10.2 Operating faults checklist

Fault	Cause/reason	Remedy
<b>Linear actuator does not work.</b>	Handwheel (36) is in manual mode position.	Switch handwheel to automatic mode position.
	Mains power failure.	Establish cause and eliminate.
	Fuse defective (in the electrical cabinet).	Establish cause and eliminate, change fuse.
	Linear actuator incorrectly connected.	Rectify connection in accordance with circuit diagram (on the cover).
	Short circuit due to humidity.	Establish cause, dry the linear actuator, change hood seal and screw connections if necessary and/or fit protective hood.
	Short circuit due to incorrect connection.	Rectify connection.
	Motor has coil damage (burnt-out) • e.g. due to too high voltage • Electronic system defective	Establish cause, measure current data. Compare with rating plate and table, Remove linear actuator and return to manufacturer for repair.
<b>2. Linear actuator runs in an unstable manner, i.e. switches between clockwise and counter-clockwise rotation.</b>	Voltage drop due to too long connecting cables and/or too small cross-section.	Measure linear actuator current data, recalculate and change connecting cables if necessary.
	Mains power fluctuations greater than permissible tolerance. See Section 2.5, <i>Technical data</i> .	Improve mains power ratios.
<b>3. Linear actuator cuts out from time to time or initialises frequently.</b>	Supply cable has loose contact.	Check and tighten connections (terminal strips).
<b>4. Linear actuator does not move to limit position. Valve does not open/close.</b>	Valve jams.	Ensure smooth running valve.
	Too high system pressure.	Correct system pressure.
<b>5. Linear actuator does not move or does not move correctly to the position specified by input signal Y.</b>	Input signal Y is faulty: • Error signals • Signal fluctuations	Check input signal Y on linear actuator, eliminate cause of fault.
	Main PCB defective.	Change motherboard, remove linear actuator and return to manufacturer for repair if necessary.
<b>6. Green LED flashes in long/long rhythm.</b>	Lock detection has responded.	Press INIT and observe actuator during initialisation.
		Check valve for smooth running over entire lift range.
<b>7. Green LED flashes in short/long rhythm</b>	Open circuit detected.	Measure reference value voltage or current on linear actuator.
<b>8. Green LED flashes in long/short rhythm</b>	Relay contact adherence.	Check control.
<b>9. Red LED flashes regularly.</b>	Actuator overheats	Motor has switched off automatically. Automatic start-up after cooling down.

Table 9 Operating faults checklist





**Contact us now**

[mail@rotork.com](mailto:mail@rotork.com)

[www.rotork.com](http://www.rotork.com)

PUB192-005-00

Issue 07/25